

Startgate STSn



The Startgate is used mainly for Alpine Skiing, but also for cross Country Skiing, Snowboard, etc. The Startgate is mounted between two posts at the start, so the racer has to move the startwand of the Startgate when he leaves the start.

To fix the Startgate at the post it has a chain bracket.



Different Startgate Types are available:

- STSnM1S:** manual reset, 1 contact, built in speech amplifier
- STSnM1:** manual reset, 1 contact, no speech amplifier
- STSnM2S:** manual reset, 2 contacts, built in speech amplifier
- STSnM2:** manual reset, 3 contacts, no speech amplifier
- STSnA1S:** automatic reset, 1 contact, built in speech amplifier
- STSnA1:** automatic reset, 1 contact, no speech amplifier
- STSnQ:** manual reset, 4 contacts, built in speech amplifier

FIS homologated Startgate: STSnM2S and STSnQ

Contacts:

ALGE offers models with one, two or four contacts. At each contact (two banana sockets) you can connect a start line. Each contact has a separate micro switch. For FIS races a separate start line is necessary for timer A and B, therefore you need a Startgate with two contacts.

Built in Speech Amplifier:

ALGE offers models with built in speech amplifiers. Such Startgates have the advantage that you can connect a headset and talk with the starter through the 2-core start cable.

Startwand Reset:

ALGE offers models with automatic and manual reset of the startwand. Automatic reset is mainly used for training and Selftimer. Startgates that are used for racing have a manual rest of the startwand, this means after the start they stay open until the starter closes them short before the next start.

Startwand STSn-S:

A new Startgate has a screw able startwand plus one reserve startwand.



ALGE
TIMING

ALGE-TIMING GmbH
Rotkreuzstrasse 39
A-6890 Lustenau
Tel: +43-5577-85966
Fax: +43-5577-85966-4
office@alge-timing.com
www.alge-timing.com